

SECTION XXXXX HYDROSTRAW® GUAR PLUS HYDRAULIC MULCH

PART 1: GENERAL

1.1 SUMMARY

- A. This section specifies the use of HydroStraw® Guar Plus as an allowable hydraulic fiber mulch for use in temporary cover by mulch, temporary cover by seeding or permanent cover by seeding applications. Do not use HydroStraw® Guar Plus as a channel liner or for areas receiving concentrated flow.
- B. Related Sections: Other Specification Sections, which directly relate to the work of this Section may include, but are not limited to the following:
1. *Section XXXXX – EARTHWORK*
 2. *Section XXXXX – LANDSCAPING*
 3. *Section XXXXX – SITE STABILIZATION*
 4. *Section XXXXX – SEEDING, FERTILIZING, AND MULCH*

1.2 APPLICATIONS

Use HydroStraw® Guar Plus to provide extra protection on difficult sites where slopes, soil conditions or weather call for extra erosion control ability. Use HydroStraw® Guar Plus when the site requires immediate erosion protection as a result of enhanced vegetation establishment.

- A. USE AS A BLOWN STRAW REPLACEMENT with hydraulically applied straw conversion.

Replace the recommended blown straw rate per acre with the recommended HydroStraw® Guar Plus rate per acre less the hydraulically applied fibers for seed, fertilizer and tackifiers application. Table 1 is an example:

Table 1: HydroStraw® Guar Plus Replacement

Example Blown Straw Specification		HydroStraw Recommendation	
Wood Fiber seed and fertilizer	500 lbs	HydroStraw seed and fertilizer	1,000 lbs
Blown Straw	4,000 lbs	HydroStraw	3,000 lbs
Wood Fiber tackifier application	500 lbs	HydroStraw	-0- lbs
TOTAL Fiber Pounds per acre:	5,000 lbs	TOTAL Fiber Pounds per acre:	4,000 lbs

B. PRE BLENDED PRODUCT

HydroStraw® Guar Plus is a pre-blended product that eliminates the extra step and mess of field mixing of mulch components and additives and reduces guar break down by rain fall events.

C. HIGHER LOADING RATES

HydroStraw® Guar Plus performance is reduced by using lower than recommended mulch to water ratio. HydroStraw® formulation is designed for maximum performance with the following mulch to water mixture ratio:

RECOMMENDED HYDROSTRAW® GUAR PLUS MIXTURE RATES

- 60 lbs per 100 Gallons for hose work
- 75 lbs per 100 Gallons for tower work

Higher loading rate reduces the amount of water required for the application of HydroStraw® Guar Plus.

D. VEGETATION ESTABLISHMENT

The annually renewable straw fiber in HydroStraw® Guar Plus enhances vegetation establishment by aiding in moisture retention and compensating for seed to soil contact. Complete soil coverage is needed to improve moisture retention and improve seed germination. Low rain fall regions may consider higher HydroStraw® Guar Plus application rates to increase soil moisture retention to improve the establishment of vegetation.

1.3 SUBMITTALS

- A. Submit the manufacturer’s product data and installation instructions. This includes but is not limited to the required site preparation, list of required materials and required application rate(s).
- B. Submit a letter from the manufacturer certifying that the hydraulic mulch fiber meets or exceeds all technical and packaging requirements.

- C. Upon request, submit from the manufacturer a *Report of Straw Analysis* test demonstrating the straw contains no viable seed. Ensure the *Report of Straw Analysis* is prepared by registered seed technologist from an accredited ISTA laboratory and is made available per product lot numbers upon request. Samples are taken during the production to represent a uniform sample.
- D. No material will be considered as an equivalent to the HydroStraw[®] Guar Plus material specified herein unless it meets all requirements of this specification, without exception. Manufacturers seeking to supply what they represent as equivalent material must submit records, data, independent test results, samples, certifications, and documentation deemed necessary by the ENGINEER to prove equivalency.

1.4 QUALITY ASSURANCE

- A. At the time of delivery, provide the ENGINEER with the specific packing list containing complete identification, including but not limited to the following:
 - 1. Manufacturer name and location.
 - 2. Manufacturer telephone number and fax number.
 - 3. Manufacturer's e-mail address and web address.
 - 4. Hydraulic mulch name, model and/or serial number.
 - 5. Certification that the specific hydraulic mulch meets the physical and performance criteria of this specification.

1.5 DELIVERY STORAGE AND HANDLING

- A. Deliver all materials in moisture resistant factory labeled packages.
- B. Store and handle HydroStraw[®] Guar Plus in strict compliance with the manufacturer's instructions and recommendations. Protect the packaged hydraulic mulch from damage from weather, excessive temperatures, and construction operations.
- C. Clean all spills promptly.

PART 2: PRODUCTS

2.1 ACCEPTABLE PRODUCTS & MANUFACTURER

A. HydroStraw® Guar Plus

HydroStraw, LLC
3676 W 9000N Road
Manteno, IL 60950
Toll Free: 800-545-1755
Fax: 815-468-7450
www.hydrostraw.com
info@hydrostraw.com

2.2 MATERIALS

A. All materials consist of HydroStraw® Guar Plus and conform to the composition requirements of Section 2.3.

2.3 COMPOSITION

The pre-packaged mulch materials consists of a specially formulated composition of annually renewable straw fiber, natural fibers for fiber matrix entanglement, a high strength guar gum polymer binder and additives to reduce guar gum break down by rain fall events.

- A. The primary mulch fiber is produced from annually renewable straw fiber.
- B. The primary tackifier is a natural guar gum tackifier.
- C. All mulch fiber materials are free from plastic materials or other non bio-degradable substances.
- D. Mulch fiber is of such character that the fiber will disperse into uniform slurry when mixed with water.
- E. Mulch fiber is colored green, and does not stain concrete or other surfaces.
- F. Mulch fiber and other mulch ingredients are free from growth or germination inhibiting ingredients.
- G. All components are pre-packaged by the manufacturer to assure both material performance and compliance with the minimum requirements of Table 2.
- H. Under no circumstances is field mixing of additives or components accepted.

Table 2: Minimum HydroStraw® Guar Plus Requirements

Property	Requirement
Physical	
Organic Matter	100%
Toxicity	Non Toxic
Applied Color	Colored green and shall not stain concrete or other surfaces.
Surface Tension	Material evenly disperses and suspends when agitated in water.
Absorbency	When sprayed uniformly at the recommended rate, the mulch fibers form an absorbent mulch cover which allows percolation of water and increased water infiltration to the underlying soil matrix
Solubility	Mulch Fibers are non water soluble
pH	6.8 +/- 0.5
Average Fiber Length	1/2" +/- 1/4"
Composition	
Heat & Mechanically Treated (HMT™) - Straw	80.0% +/- 1.0%
Natural Fibers	6.0% +/- 1.0%
Moisture	10.0% +/- 1.0%
Guar Based Tackifier	4.0% +/- 1.0%

2.4 **PACKAGING**

A. Ensure all products are packaged in the following manner:

1. Bag Size: 11.5"W x 17"D x 25"H
2. Bags Weight: 50 lb compressed bales
3. Packaging: Moisture resistant package protected
4. Pallet: 40 bags/pallet (52"W x 45"D x 96"H)

PART 3: EXECUTION

3.1 EXAMINATION

- A. Use HydroStraw[®] Guar Plus where all components are pre-packaged by the manufacturer to assure material performance.
- B. Examine substrates and conditions before applying materials. Do not proceed with installation until unsatisfactory conditions are corrected. Apply hydraulic mulch to stable slopes that are constructed to divert runoff water away from the face of the slope, eliminating damage to the slope face caused by the surface flow from above the slope.

3.2 INSTALLATION

- A. Use personnel or subcontractors experienced in the proper procedures for mixing and application of hydraulic mulch. Use personnel or subcontractors certified and trained by the manufacturer in the proper procedures for mixing and application of hydraulic mulch.
- B. Strictly comply with the manufacturer's installation and mixing instructions shown in Table 3.

Table 3: HydroStraw[®] Guar Plus Mixture Rates

Mulch Fiber Weight (lbs)	Gallons of Water
60	100 (hose work)
75	100 (tower work)

- C. Loading and Mixing Instructions
 - 1. Start the flow of water into the tank.
 - 2. Pre-wet hoses and prime the pump by running water through the lines.
 - 3. Engage the agitator at ½ speed.
 - 4. When applying seed and/or fertilizer, add to the tank when the water level reaches ¼ full.
 - 5. **Load all HydroStraw[®] Guar Plus components before the tank reaches ¾ full. Do not hesitate to shut off water before this step is completed.**
 - 6. Resume filling the tank with water until the tank is full.

- 7. Set the engine to full throttle for approximately ½ minute. Then set the engine throttle to about ½ speed to begin hose application operations.
- D. It is imperative to apply the mulch at the specified mixture rate: too wet of a mixture will cause the fibers to be buried into the soil and also dilutes the fiber binders reducing effectiveness.
- E. Apply Mulch Fiber as a slurry solution by means of approved hydraulic seeding/mulching machines with appropriate nozzles for hydraulic mulch applications.
- F. Apply Mulch Fiber at the specified rates per in Table 4 in a uniform manner.

Table 4: Minimum HydroStraw® Guar Plus Application Rates

Slope Gradient	lb/acres
S ≤ 4:1	2,000
4:1 < S ≤ 3:1	3,000
3:1 < S ≤ 2:1	4,000
Soil Moisture Retention	2,000 – 3,500

- G. Ensure the mulch application is uniform and even throughout the seeded area. Ensure the mulch is not bunched or clumped up on the site.
- H. Avoid creating a “shadowing effect” on the site. Apply mulch fiber from opposing directions to the soil surface in successive layers, reducing the “shadow effect” to achieve maximum coverage of all exposed soil. Start mulch applications on the windward side of the project.
- I. Add seed, lime, and fertilizer as outlined in Section XXXXX *SEEDING, FERTILIZING, AND MULCH*.
- J. Ensure seed to soil contact best management practices are utilized. Improved seed germination and establishment can be achieved by improving the seed to soil contact by drilling or broadcasting the seed application prior to HydroStraw® Guar Plus application.

Applying the seed (Hydroseeding) with HydroStraw® Guar Plus at a rate of 1,000 lbs or less per acre during a first pass application is another option. In this situation, the balance of the targeted HydroStraw® Guar Plus rate is applied during the second pass application to cover the seed and soil creating an ideal environment for seed germination and establishment.

3.3 INSPECTION AND MAINTENANCE

A. Prepare a maintenance plan that includes the following:

1. Reapplication as directed by the ENGINEER to disturbed areas that require continued erosion control.
2. Maintenance of equipment to provide uniform application rates.
3. Rinsing all mixing and application equipment thoroughly with water to avoid formation of residues and appropriate discharge of rinse water.

B. Degradation can be expected to occur as a result of mechanical degradation, chemical degradation, biological hydrolysis, sunlight, salt, and temperature. Where necessary, reapply in accordance with the manufacturer's instructions. Reapplication is not required unless treated soils are disturbed or turbidity or water quality shows the need for an additional application. If treated soils are left undisturbed, the necessity of reapplication is determined by the ENGINEER.

C. Payment for the reapplication is not made unless the reapplication is approved by the ENGINEER.

PART 4: ACCEPTANCE MEASUREMENT AND PAYMENT

4.1 ACCEPTANCE

Obtain acceptance and approval of HydroStraw® Guar Plus installation from the ENGINEER. When requested by the ENGINEER, ensure that a manufacturer's representative is on-site to oversee and approve the initial installation. Obtain a letter from the manufacturer approving the installation when requested by the ENGINEER.

4.2 MEASUREMENT

The quantity for the pay item HydroStraw® Guar Plus is the surface area covered by the hydraulic mulch applied at the recommended rate and is measured by the one-acre (acre) unit in-place, complete, and accepted. The installation may require written acceptance by the manufacturer's representative before acceptance for payment.

4.3 PAYMENT

Payment for HydroStraw® Guar Plus is full compensation for installing the hydraulic mulch as specified or directed by the ENGINEER and includes furnishing, applying, and maintaining the hydraulic mulch including testing and documentation of Quality Control and Quality Assurance programs and all other materials, labor, equipment, tools, supplies, transportation, and incidentals necessary to fulfill the requirements of the pay item in accordance with the Plans, the Specifications, and other terms of the Contract.

END OF SECTION